

Extreme Shock Battery End Cap for 'E' Style Lighted Nock Installation Manual

This end cap will only work in ACC349, ACC ProHunter, Epic size arrows

Extreme Shock End Cap Installation:

- Remove the plastic nock that comes with the arrow.
- Remove broadhead/field tip.

Note: Back pressure can cause glue to not set if broadhead or field point is not removed.

- Roll the O-ring onto the tool (Fig 1)
- Screw the end cap onto the tool (Fig 2)
- Roll the O-ring on the tool onto the first available groove on the end cap. (Fig 3)

Note: If you decide to use gel type super glue, please practice inserting the end cap first before applying glue inside the arrow shaft to ensure that you can insert the end cap within a few seconds.

- Clean the inside of the shaft with acetone using a Q-tip, then let dry.
- Apply a bead of super glue gel to the inside surface of the shaft (super glue gel such as Firenock AG-0GEL is recommended).
- While the glue is still wet, insert the end cap, with pointed side first into the arrow shaft. The O-ring ensures that most of the glue is pushed to the back behind the end cap.
- Push the tool until it is flush with the arrow shaft. (Fig 4)
- Hold the arrow with nock side down for 30 seconds to ensure glue sets around the O-ring.
- Try to tighten the tool a little; if it feels finger tight, the end cap is installed properly.
- Unscrew the tool from the shaft. (Fig 5)
- If the end cap is still loose, repeat steps (f) thru (m) as instructed above.

Note: If you do not want to wait, tape over the battery and connectors to prevent glue vapor deposit over the battery and the connector which will render the battery and Firenock useless.

- Wait till glue totally dries, or thin glue film will form on the battery and render the battery useless.
- Follow the rest of the installation manual that comes with your Firenock "E" style to complete the installation of your lighted nock.

Note: It is not necessary to install the O-ring on the battery casing as the Extreme Shock End Cap has a built in battery holding cup. Doing so has no effect except adding weight to your arrow.

Schematic installation procedures for Extreme Shock Battery End Cap for G Series 'E' Style Lighted Nock

Fig 1



Fig 2



Fig 3



Fig 4



Fig 5

